



ARIUS YDP-164, YDP-144, YDP-S54 快速操作指南

按住相应按钮的同时，按下如下所示的突出显示琴键之一选择示范曲或设置参数。

1 乐曲播放

快速播放 **示范乐曲** **50首预设乐曲 (50 Classical Music Masterpieces) 乐曲编号** **从计算机载入的乐曲数据**

DEMO/SONG +

Off On C0 D0 E0 F0 G0 A0 B0 C1 D1 E1 F1 G1 A1 B1 C2 D2 E2 F2 G2 A2 B2 C3 D3 E3 F3 G3 A3 B3 C4 D4 E4 F4 G4 A4 B4 C5 D5 E5 F5 G5 A5 B5 C6 D6 E6 F6 G6 A6 B6 C7

* 50首预设乐曲 (50 Classical Music Masterpieces) 乐曲编号/乐曲名

| | | | | |
|---|---|---|---------------------------------------|--------------------------------|
| 1 Canon D dur | 11 Salut d'amour op.12 | 21 Prelude (Wohltemperierte Klavier I No.1) | 31 Etude op.10-3 "Chanson de l'adieu" | 41 Humoresque |
| 2 Air On the G String | 12 From the New World | 22 Menuett G dur BWV Anh.114 | 32 Etude op.10-12 "Revolutionary" | 42 Arietta |
| 3 Jesus, Joy of Man's Desiring | 13 Sicilienne | 23 Piano Sonate No.15 K.545 1st mov. | 33 Valse op.64-1 "Petit chien" | 43 Tango (España) |
| 4 Twinkle, Twinkle, Little Star | 14 Clair de lune | 24 Turkish March | 34 Nocturne op.9-2 | 44 The Entertainer |
| 5 Piano Sonate op.31-2 "Tempest" 3rd mov. | 15 Jupiter (The Planets) | 25 Piano Sonate op.13 "Pathétique" 2nd mov. | 35 Nocturne KK4a-16/BI 49 [Posth.] | 45 Maple Leaf Rag |
| 6 Ode to Joy | 16 Menuett (Eine kleine Nachtmusik K.525) | 26 Für Elise | 36 Träumerei | 46 La Fille aux Cheveux de Lin |
| 7 Wiegenlied op.98-2 | 17 Menuett G dur | 27 Piano Sonate op.27-2 "Mondschein" 1st mov. | 37 Barcarolle | 47 Arabesque No.1 |
| 8 Grande Valse Brillante | 18 Marcia alla Turca | 28 Impromptu op.90-2 | 38 La prière d'une Vierge | 48 Cakewalk |
| 9 Polonaise op.53 "Héroïque" | 19 Piano Concerto No.1 op.11 2nd mov. | 29 Frühlinglied op.62-6 | 39 Liebesträume No.3 | 49 Je te veux |
| 10 La Campanella | 20 The Nutcracker Medley | 30 Fantaisie-Impromptu | 40 Blumenlied | 50 Gymnopédies No.1 |

2 音色设置

音色 **混响类型** **混响深度** **制音共鸣** **立体声优化器** **音色1和音色2之间的平衡** **八度设置** **力度灵敏度**

PIANO/VOICE +

CFX Grand Mellow Grand Stage E.Piano Harpsichord Pipe Organ Strings Recital Hall Chamber 关 降1 升1 关 开 关 开 默认设置 默认设置 -1 (音色2) 0 (音色2) +1 (音色2) -1 (音色1) 0 (音色1) +1 (音色1) Soft Hard Medium Fixed

A-1 B-1 C0 D0 E0 F0 G0 A0 B0 C1 D1 E1 F1 G1 A1 B1 C2 D2 E2 F2 G2 A2 B2 C3 D3 E3 F3 G3 A3 B3 C4 D4 E4 F4 G4 A4 B4 C5 D5 E5 F5 G5 A5 B5 C6 D6 E6 F6 G6 A6 B6 C7

ARIUS YDP-164, YDP-144, YDP-S54 快速操作指南

3 节拍器设置

当前速度值的音色确认 **节拍器音量** **速度 (节拍器, 乐曲等)** **节拍器节拍**

METRONOME +

降1 升1 默认值 降1 升1

1 3 5 7 9 2 4 0 3 5 6

A#-1 C#0 D#0 F#0 G#0 A#0 C#1 D#1 F#1 G#1 A#1 C#2 D#2 F#2 G#2 A#2 C#3 D#3 F#3 G#3 A#3 C#4 D#4 F#4 G#4 A#4 C#5

A-1 B-1 C0 D0 E0 F0 G0 A0 B0 C1 D1 E1 F1 G1 A1 B1 C2 D2 E2 F2 G2 A2 B2 C3 D3 E3 F3 G3 A3 B3 C4 D4 E4 F4 G4 A4 B4 C5

将数值增大1: METRONOME + + [R]

将数值减小1: METRONOME + - [L]

4 其他设置

操作确认音 **自动关机** **当前系统版本的音色确认** **调音** **IAC 深度** **移调** **MIDI发送通道** **MIDI接收通道** **本机控制** **控制变更** **程序变更** **音频循环返送** **扬声器开/关** **乐曲播放频道**

DEMO/SONG + PIANO/VOICE

开 禁用 启用 440.0 Hz 442.0 Hz 关 降1 升1 -5 -4 -2 0 (标准音高) +1 +3 +5 通道1 关 通道1 通道1+2 开/关 开/关 关 关 标准 所有 通道1+2

A#-1 C#0 D#0 F#0 G#0 A#0 C#1 D#1 F#1 G#1 A#1 C#2 D#2 F#2 G#2 A#2 C#3 D#3 F#3 G#3 A#3 C#4 D#4 F#4 G#4 A#4 C#5 D#5 E5 F5 G5 A5 B5 C6 D6 E6 F6 G6 A6 B6 C7

A-1 B-1 C0 D0 E0 F0 G0 A0 B0 C1 D1 E1 F1 G1 A1 B1 C2 D2 E2 F2 G2 A2 B2 C3 D3 E3 F3 G3 A3 B3 C4 D4 E4 F4 G4 A4 B4 C5

5 调音设置

按住[PIANO/VOICE]按钮, 同时按下[+R]和[-L]按钮以打开或关闭双人模式。

上调音高 (以约0.2 Hz为单位):

下调音高 (以约0.2 Hz为单位):

默认音高: 440.0 Hz

6 双人设置

按住[DEMO/SONG]和[PIANO/VOICE]按钮的同时, 按下如下所示的[+R]、[-L]或2个按钮以微调乐器音高。

打开或关闭双人模式:

Manual Development Group
© 2018 Yamaha Corporation
2019年5月 发行 CSMA*.* **A0

VCH3990

ZH